



ENGINEERING, INC.  
52965 FREDERIC DRIVE  
ELKHART, IN 46514

**REMOVAL OF CLASS A**  
**MIRROR ASSEMBLY**  
**FRONT MOUNTED**

**Removal of Arm/Mirror Head from Mounting Bracket**

1. Locate cap with Ramco logo on bottom of mount covering (shroud) and remove using a small flat-head screwdriver. This will expose the bolt that attaches the arm to the mount.
2. Using a 9/16" socket, remove the bolt.
3. Once the bolt is removed, lift the arm out of the mounting bracket. If the arm does not come out easily, use a rubber mallet and tap on the bottom of the arm to loosen it.
4. Once the arm has been removed, disconnect the wire harness. If there is not a quick disconnect, the wire will have to be cut. Be sure to allow enough slack in the wire so when reconnecting there will be enough wire to work with. (Allow about 4-6" out of mounting bracket and 3-4" out of arm)

**Removal of Mounting Bracket from Coach**

1. Remove plastic covering (shroud) from mounting bracket.
2. Remove the four (4) mounting screws securing the mounting bracket to the coach.

**Installation of New Assembly**

1. Take mounting bracket and pull any wiring up through the back and out.
2. Secure the mounting bracket to the coach with four (4) screws.
3. Place shroud over mounting bracket.
4. Reconnect the wire harness. **Test electrical function before proceeding to next step.**
5. Place arm into mounting bracket and tighten bolt. Do not fully tighten until arm is positioned correctly.
6. Slightly loosen set screws holding the mirror head in place and adjust to the driver's needs. Once desired adjustment is made, tighten the set screws and mounting bolt.

*Engineered To See America Better!!*

Phone: (574) 266-1455 | (800) 321-4819 | Fax: (574) 266-1420